Anleitung PTS-Lackstift



 Den kompletten Verschluss-Stopfen mit kleinen, ruckartigen Bewegungen aus der Aluhülse ziehen.



 Verschlusskappe mit Lack-Pulver füllen und in den Lackstift einfüllen.



 Das Pulver mit dem Lackstiftpinsel ca. 2 Minuten gründlich und klumpenfrei in die Tinktur einrühren.



4. Den kompletten Verschluss-Stopfen wieder in die Aluhülse einpressen (ggf. mit einem Gummihammer oä.)



Lackstift vor jedem Gebrauch
 ca. 2 Minuten kräftig schütteln.
 Danach mit dem Pinsel auftragen.
 Dann den Lack mindestens
 30 Minuten gut trocknen lassen.



Instruction PTS paint stick



 The complete sealing plug with small and jerky movements to pull it out of the aluminum sleeve.



2. Fill the cap with varnish powder and fill it into the touch-up pen.



3. Apply the powder with the touch-up brush for ca. 2 minutes to the tincture lump-free into the tincture.



 Press the complete sealing plug back into the aluminum sleeve (if necessary with a rubber mallet or similar).



 Before each use, shake the paint stick shake vigorously for ca. 2 minutes.
 Then apply with the brush.
 Then allow the varnish to dry well for at least 30 minutes to dry thoroughly.

